

Jøtul F 370 Noncatalytic Woodburning Stove

Installation and Operating Instructions for the United States & Canada



Installation and Operation Instructions for USA/Canada

Safety notice: If this solid fuel room heater is not properly installed, a house fire may result. For your safety, follow the installation directions. Contact local building or fire officials about restrictions and installation inspection requirements in your area. Save these instructions for future reference and make them available to anyone using or servicing this stove.

Installation et fonctionnement pour Canada

Avis de sécurité: Une installation non appropriée de ce poêle de chauffage risque de provoquer un incendie. Assurez votre sécurité en respectant les directives d'installation suivantes. Consultez les autorités locales du bâtiment ou de la prévention des incendies au sujet des restrictions et exigences relatives aux inspections d'installations dans votre région.

For Your Records...

Record the following information to help your dealer determine what you will need should your fireplace ever require parts or service.

The serial number and manufacturing date are located on the aluminum label attached to the bottom of the firebox. Attach your sales receipt to this manual for future reference.

Model: Jøtul F 370 Serial Number: Purchase Date: Dealer Name:

Phone:

Installed by:

Table of Contents

1. General Information

| 1.1. Test Standards | 3 |
|-------------------------------|---|
| 1.2 Combustion Specifications | 3 |
| 1.3 Codes | 3 |
| | |

3. Installation Requirements

| 3.1 Chimney Requirements | - 5 |
|--|-----|
| 3.2 Chimney Connector Requirements | . 6 |
| 3.3 Floor Protection | .9 |
| 3.4 Clearance to Combustible Materials | .9 |

4. Assembly

| 4.1 Tools & Materials | 11 |
|---------------------------------------|----|
| 4.2 Unpacking the Stove | 11 |
| 4.3 Install Anchor Bracket | 13 |
| 4.4 Assemble the Firebox and Pedestal | 12 |
| 4.5 Position the Stove | 13 |
| 4.6 Chimney Connection | 13 |
| 4.7 Secure Stove to Hearth | 14 |
| 4.8 Final Assembly | 14 |
| | |

5. Operation

| • | |
|---------------------------------------|----|
| 5.1 Combustion Efficiency | 15 |
| 5.2 CO Emissions | 15 |
| 5.3 Wood Fuel and Stove Performance | 15 |
| 5.4 Air Control | 16 |
| 5.5 Break-in Procedure | 16 |
| 5.6 Starting and Maintaining the Fire | 17 |
| 5.7 Adding Fuel | 17 |
| 5.8 Creosote and the Need for Removal | 17 |

6. Maintenance

| 6.1 Ash Removal | 18 |
|-------------------------------|----|
| 6.2 Chimney System Inspection | 18 |
| 6.3 Glass Care | 18 |
| 6.4 General Maintenance | 19 |
| 6.5 Gaskets | 19 |

1. General Information

1.1 Test & Listing Standards

The Jøtul F 370 Solid Fuel Room Heater has been tested for compliance with the applicable requirements of the following standards:

UL 1482-2000 "Solid-Fuel Type Room Heaters" and ULC S627-2000 "Standard for Space Heaters for use with Solid Fuels".

Certified Safety Tests performed by **ITS, Intertek Testing Services** Middleton, WI



Manufactured by: Jøtul North America 55 Hutcherson Drive Gorham, Maine 04038-2644

This manual describes the installation and operation of the Jøtul F 370 non-catalytic wood heater. Save these instructions and make them available to anyone using or servicing the stove. Read the entire manual before you install and use your new wood stove.

This wood heater needs periodic inspection and repair for proper operation. See this manual for specific information. It is against federal regulations to operate this wood heater in a manner inconsistent with the operating instructions in this owner's manual.

The Jøtul F 370 is listed to burn solid or compressed wood only. Do not burn any other fuels.

THIS APPLIANCE IS NOT APPROVED FOR USE IN **MOBILE HOMES.**

1.2 Combustion Specifications

Heat Output: Under specific laboratory test conditions, this heater has shown heat output at rates ranging from 10,975 to 29,050 BTU's per hour. Actual heat output will vary depending upon fuel type and quality, home design, climate, environment, operation, and chimney function.

| Efficiency*: | 63% | | |
|-----------------------|-----------------|--|--|
| CO Emissions: | N/A | | |
| Pariculate Emissions: | 2.6 g/hr | | |
| Max. Log Length: | 12 in. / 300 mm | | |

Default values per previous Federal Register 40 CFR Part 60, Subpart AAA.

EPA validated efficiency and CO values were unavailable at the time of this printing. These values will be made available in the manual and on the Jotul website (www.jotul.us) for your reference in the near future.

WARNING !

THIS WOOD HEATER HAS A MANUFACTURER-SET MINIMUM LOW BURN RATE THAT MUST NOT BE ALTERED. IT IS AGAINST FEDERAL **REGULATIONS TO ALTER THIS SETTING OR OTHERWISE OPERATE THIS WOOD** HEATER IN A MANNER INCONSISTENT WITH **OPERATING INSTRUCTIONS IN THIS MANUAL.**

This heater meets the 2015 U.S. Environmental Protection Agency's emission limits for wood heaters manufactured after May 15, 2015.

See Sect. 5.0 of this manual for important information regarding the safe, proper, and most efficient operation of your stove.

1.3 Check Building Codes

When installing, operating and maintaining your Jøtul F 370 Fireplace Insert, follow the guidelines presented in these instructions, and make them available to anyone using or servicing the stove.

In the U.S., guidelines established by UL 1777, the National Fire Protection Association's Code, NFPA 211, Standards for Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances, or similar regulations, may apply to the installation of a solid fuel burning appliance in your area. For further information on using your heater safely, obtain a copy of the NFPA publication "Using Coal and Wood Stoves Safely," NFPA No. HS-8-1974, available from NFPA

470 Atlantic Ave. Boston, MA 02210.

In Canada, the guidelines are established by ULC-S635, and the CSA Standard, CAN/CSA-B365-M93, Installation Code for Solid-Fuel-Burning Appliances and Equipment.

Always consult your local building inspector or authority having jurisdiction to determine what regulations apply and what permits may be required before installation of a solid fuel-burning appliance.

Notify your insurance company before installing this stove.



Training (WETT). www.nficertified.org



2. Safety Notices

- BURN SOLID WOOD FUEL ONLY
- DO NOT USE CHEMICALS OR FLUIDS TO START THE FIRE. DO NOT BURN GARBAGE, TRASH, OR FLAMMABLE FLUIDS.
- IF THIS ROOM HEATER IS NOT PROPERLY INSTALLED, A HOUSE FIRE MAY RESULT. TO REDUCE THE RISK OF FIRE, FOLLOW THE INSTALLATION INSTRUCTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR LOSS OF LIFE.
- CONTACT THE LOCAL BUILDING OR FIRE OFFICIALS ABOUT RESTRICTIONS AND INSTALLATION INSPECTION REQUIREMENTS IN YOUR AREA. WHEN NOT ADDRESSED IN THIS MANUAL, OR BY LOCAL CODE AUTHORITIES, INSTALLATION SPECIFICATIONS AND REQUIREMENTS DEFER TO NFPA 211 OR CSA B 365
- DO NOT CONNECT THIS FIREPLACE TO ANY AIR DISTRIBUTION DUCT OR SYSTEM .

9 3/4"

8 3/4" 221mm

- EXTREMELY HOT WHILE IN OPERATION! KEEP CHILDREN, CLOTHING AND FURNITURE AWAY. CONTACT WILL CAUSE SKIN BURNS.
- NEVER LEAVE SMALL CHILDREN UNSUPERVISED IN THE SAME ROOM WITH THE STOVE. USE A CHILD-GUARD SCREEN OR OTHER BARRIER TO PROTECT CHILDREN FROM ACCIDENTAL CONTACT.
- NEVER OPERATE THE FIREPLACE WITH A CRACKED OR BROKEN GLASS PANEL.
- Install smoke detectors in the living areas and bedrooms of your home. Test them regularly and install new batteries twice annually. When installed in the same room as the stove, a smoke detector should be located as far from the stove as possible to prevent it from sounding when adding fuel to the fire. Some jurisdictions require installation of CO (carbon monoxide) detectors. Check your local codes.
- Avoid creating a low pressure condition in the room where the stove is operating. Be aware that operation of an exhaust fan or clothes dryer can create a low pressure area and consequently promote flow reversal through the stove and chimney system. The chimney and building, however, always work together as a system provision of outside air, directly or indirectly to an atmospherically vented appliance will not guaranty proper chimney performance. Consult your local Jøtul authorized dealer regarding specific installation or performance issues.





- Flue Outlet: Top or Rear Exit
- Flue Outlet Adaptor Dia: 6 in. / 153 mm
- Weight: 344 lbs. / 156 kg

Figure 1. Jøtul F 370 dimensions.

3. Installation Requirements

3.1 Chimney Requirements

There are two types of approved chimneys:

- 1. A code-approved masonry chimney with a ceramic tile or listed steel flue liner.
- 2. A prefabricated chimney complying with the requirements for Type HT (2100°F) chimneys per UL 103 HT or ULC S629 HT.

3.1.1 Chimney Flue Sizing

The chimney size should not be less than the crosssectional area of the flue collar, and not more than three times greater than the cross-sectional area of the flue collar.

If the chimney flue is outdoors, its cross-sectional area may not exceed two times greater than the stove flue collar.

A chimney flue having no walls exposed to the outside below the roof-line may be no larger than three-times the cross-sectional area of the stove flue collar.

3.1.2 Design Considerations

When selecting a chimney type and the location for the chimney in the house, keep this in mind: It is the chimney that makes the stove work - not the stove that makes the chimney work. This is because a chimney actually creates a suction, called "draft" which pulls air through the stove.

Several factors affect draft: chimney height, crosssectional area (size), and temperature of the chimney, as well as the proximity of surrounding trees or buildings.

A short exterior masonry chimney will give the poorest performance because it will be difficult to warm the flue and sustain the temperatures necessary to maintain draft strength. In extremely cold climates, it may be necessary to reline the chimney or extend the height to help establish draft.

A tall, interior masonry chimney is easier to keep warm and will perform the best under a variety of weather and environmental conditions.

The following guidelines give the necessary chimney requirements based on the national code (ANSI-NFPA 211 for the US. And CSA CAN-B365 for Canada). However, many local codes differ from the national code to take into account climate, altitude, or other factors. Your local building inspector is the final approving authority.

3.1.3 Masonry Chimneys

Follow these guidelines when installing the stove into a masonry fireplace:

- The masonry chimney must have a fireclay liner or equivalent, with a minimum thickness of 5/8" (14 mm) and must be installed with refractory mortar. There must be at least 1/2" (12.7 mm) air space between the flue liner and chimney wall.
- The fireclay flue liner must have a nominal size of 8" X 8" (20 cm x 20 cm), and should not be larger than 8"X 12" (20 cm x 30 cm). A round fireclay liner must have a minimum inside diameter of 6" (15 cm) and maximum inside diameter of 8" (20 cm). A larger chimney should be relined with an appropriate code approved liner.
- Brick or modular block must be a minimum of 4" (10 cm) nominal thickness. Stone construction must be at least 12" (30 cm) thick.
- A newly-built chimney must conform to local codes, or, in their absence, must comply with national regulations.
- An existing chimney must be inspected by a professional, licensed chimney sweep, fire official, or code officer to ensure that the chimney is in proper working order. Any repairs must be completed before installing the stove.
- No other appliance may be vented into the same flue.
- An airtight clean-out door should be located at the base of the chimney.

3.1.4 Prefabricated Chimneys

A prefabricated metal chimney must be tested and listed for use with solid fuel burning appliances; High Temperature Chimney Standard UL 103 HT for the U.S. and High Temperature Standard ULC S-629 HT for Canada.

The manufacturer's installation instructions must be followed precisely. Always maintain the proper clearance to combustibles as established by the pipe manufacturer. This clearance is usually a minimum of 2", although it may vary by manufacturer or for certain chimney components.

3.1.5 Chimney Height

The chimney must be at least 15 feet high (4.57 m). The chimney must also be at least 3 feet (92 cm) higher than the highest point where it passes through the roof and at least 2 feet (61 cm) higher than the highest part of the roof or structure that is within 10 feet (3.05 m) of the chimney, measured horizontally. See fig. 2.

Chimneys shorter than 15 feet may not provide adequate draft. Inadequate draft can result in smoke spillage when loading the stove, or when the door is open. Poor draft can also cause back puffing (ignition of gas build-up inside the firebox) and sluggish performance. The minimum height does not, in itself, guarantee proper chimney performance. Optimum draft force should be in the .05 - .10 in. w.c. range measured by a Magnahelic gauge. Draft at .07 w.c. is ideal.

Excessive chimney height can promote over-strong draft resulting in high stove temperatures and short burn times. Excessive draft can be corrected by installing a butterfly damper. Your Jøtul dealer is an expert resource to consult regarding draft issues or other performance-related questions.

3.2 Chimney Connector Requirements

Use 6" single wall or listed 6" double-wall stovepipe to connect the stove to the chimney. Single wall stovepipe must be black steel or stainless steel and have a minimum thickness of 24 gauge.

Do not use aluminum or galvanized steel pipe for chimney connection - these materials are not suitable for use with solid fuel.

Follow these guidelines:

- Do not use chimney connector as a chimney. It is intended only as a connection device.
- Each connector section must be oriented with the male (crimped) end pointing toward the stove. See fig. 3.
- Secure all connector joints with three sheet metal screws. Use four self-tapping sheet metal screws at the connection to the stove flue collar adaptor.
- For the best performance, the chimney connector should be as short and direct as possible, including no more than two 90° elbows.
- The maximum vertical run of single wall stovepipe should not exceed 10 ft. (305 cm).
- The maximum horizontal run should not exceed 3 ft. (92 cm) with a 1/4" rise per foot. Under no circumstance should horizontal pipe be allowed to slant down toward the chimney.



Figure 2. Chimney height requirements.



Figure 3. Chimney connector orientation.

- No part of the chimney connector may pass through an attic or roof space, closet or other concealed space, or through a floor or ceiling. All sections of the chimney connectors must be accessible for cleaning. Where passage through a wall or partition of combustible construction is desired, the installation must conform with NFPA 211 or CAN/ CSA-B365, and is also addressed in this manual.
- Do not connect this stove to a chimney flue serving another heating appliance.

3.2.1 Connecting to the Chimney

Masonry Chimney

When installing a Stove into a masonry chimney through a "thimble" (the opening through the chimney wall to the flue), the thimble must consist of ceramic tile or steel and be securely cemented in place.

The chimney connector/stove pipe must slide completely inside the thimble to the inner surface or the flue liner. It may be necessary to make use of a thimble sleeve (a pipe with a slightly smaller diameter than standard stove pipe). See figs 4.

The connector pipe or thimble sleeve must not protrude into the flue liner or otherwise restrict draft.

Use refractory cement to seal the seam between the chimney connector, sleeve, and thimble.

Do not connect this stove to a chimney flue servicing another appliance of any kind.



Figure 4. Masonry chimney connection through a thimble.



specifications. See fig. 5.

Figure 5. Connection to prefabricated chimney.

3.2.2 Wall Pass-Throughs

Note: In addition to the methods described here, any listed, prefabricated wall pass-through components available from chimney manufacturers may be used.

In the U.S.

The National Fire Protection Association's publication, NFPA 211, *Standard for Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances* permits four methods for passing through a combustible wall. Before proceeding with any method be sure to consult with your local building officials to discuss any local code requirements.

Common Method:

See fig. 6 Remove all combustible materials from the pass-through area (around the chimney connector), a minimum 12" (30.5 cm). A 6" (15.2 cm) diameter connector will require a 31 1/4" x 31 1/4" (79.4 x 79.4 cm) square opening.

The opening must be filled with at least 12" (30.5 cm) of brick around a fireclay liner. The liner must be ASTM C35 or equivalent, having a minimum wall thickness of 5/8" (16 mm).

The Pass-through must be at least 18" (45.7 cm) from combustible ceiling materials.

It will be necessary to cut wall studs, install headers, and construct a sill frame to maintain the proper dimensions and to support the weight of the brick.

The bricks must be solid brick with a minimum of 3 inches thick (nominal 4"/ 102 mm).

Refractory mortar must be used at the junction of the chimney and the pass-through liner. The passthrough liner must not penetrate the chimney liner beyond the inner surface of the chimney liner. Use extreme care when constructing the hole in the chimney liner as the tiles can shatter easily.

In Canada

The installation must conform to CAN/CSA-B365, Installation Code for Solid Fuel Burning Appliances and Equipment. Before proceeding be sure to consult your local building inspector.

Common Method:

This method requires the removal of all combustible materials from at least 18" (45.7 cm) around the chimney connector's proposed location. A 6" round liner requires a minimum opening 43 1/4" x 43 1/4" (109.8 x 109.8 cm) square.

Locate the pass-through at least 18" from combustible ceiling materials.



Figure 6. Chimney connection to masonry chimney.

The space that is cleared of combustible materials must remain empty. Sheet metal panels can be used to cover the area. However, when using a panel on both sides of the wall, each cover must be installed on noncombustible spacers at least 1" from the wall. If one panel of sheet metal is to be used it may be installed flush to the wall.

See section 5.3.1 and 5.3.2 of CAN/CSA - B365-M91.

Consult your local building inspector, authorized Jøtul Dealer, NFPA 211 in the U.S. or CAN/CSA-B635 in Canada for other approved wall pass-through methods.

3.3 Floor Protection

Any floor that is not composed of concrete poured on earth requires protection from sparks and embers. The Jøtul F 370 is approved for installation using one of the following forms of hearth protection:

- 1) Any UL, ULC, or Warnock Hersey Listed Type 1 hearth board.
- 2) Any noncombustible material.
- In the U.S. floor protection must extend forward from the door opening at least 16 in. and 8 in. from the sides of the door opening. Protection must also extend 2 in. under the chimney connector. This will result in a minimum floor protector 29 1/2" wide x 33 3/4" deep. See fig 7.
- In Canada, floor protection must extend 18" from the front of the stove and 8 in. (460mm) from the sides and rear. It must also extend 2 in. (51 mm) under the chimney connector. This results in a floor protector 33 1/2 in. x 43 3/4 in. (85 cm x 111 cm). See fig. 7.

Figure 7. Floor protection dimensions.



| u.s. 🕂 | | | | | ĺ |
|----------|----------|-----|-----|--------------|---|
| | | | | | |
| c | | | Y | | |
| | 1 | в 🖛 | | - - B | - |
| | D | | A - | | - |
| <u> </u> | <u> </u> | | | | |

* measured from the door opening - U.S. only

| | Α | В | C | D | E |
|------|----------------------------------|--------------|--------------------|---------------|------|
| U.S. | U.S. 29 1/2" 8"* 750mm 203 mm | | 33 3/4" 857 mm | 16" 406 mm | 2" |
| CAN. | 33 1/2" 851 mm | 8" 203 mm | 43 3/4" 1111 mm | 18" 457 mm | 51mm |

Floor Protection Extension From Corner

| See fig. 8a | C/I | F | L |
|--|---------|---------|---------|
| Stove Clearance to Wall: | 16" | 8 1/2" | 6" |
| Hearth Depth from Corner:* * Canada: add 2" | 58 1/2" | 47 3/4" | 44 1/4" |



3.4 Clearance to Combustible Materials

The clearances listed and diagramed in this manual have been tested to UL and ULC standards and are the minimum clearances to combustible materials specifically established for the Jøtul F 370.

- A combustible surface is anything that can burn (i.e. sheet rock, wall paper, wood, fabrics etc.).
- Any combustible material must be kept 36" (914mm) away from the stove load door and at least 18" (457mm) from the sides.
- Combustible materials are not limited to those that are visible and also include materials that are behind noncombustible materials. "Fire Resistant" or "Firerated" materials are considered combustible; they are difficult to ignite, but will burn.
- Consult your local fire officials if you are unsure of the combustible nature of any material.

3.4.1 Clearance to Walls & Ceilings

See the table in fig.8. for specific wall clearance requirements using either single or listed double-wall connectors.

Minimum Ceiling Height: 72" / 183 cm

The F 370 is approved for use with Listed double wall pipe installed to conform to the clearances in fig. 8a.

Wall-Mounted Protection: When reducing clearances through the use of wall-mounted protection:

- For the U.S., refer to NFPA 211, Standard for Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances, for acceptable materials, proper sizing and construction guidelines.
- For Canada, refer to CAN/CSA-B365, Installation Code for Solid-Fuel Burning Appliances and Equipment, also for acceptable materials, proper sizing and construction guidelines.

Notice: Many manufacturers have developed woodstove accessories that permit clearance reduction. Use only those accessories that have been tested by an independent laboratory and carry that laboratory's testing mark. Be sure to follow all of the manufacturer's instructions.

3.4.2 Rear Exit Clearances

The stove position will be determined by the greater of either the stove clearance or the chimney connector clearance above (x) and to the side (y). See fig. 8.

| | Unprotected Surface | Protected Surface |
|-------------------|---------------------|-------------------|
| Single Wall Pipe: | 18" / 458 mm | 6" / 153 mm |
| Double Wall Pipe: | Mfg's Listing | Mfg's Listing |

| THIS CHART IS NOT VALID FOR | UNPROTECTED WALLS | | PRC | LLS | | |
|---|-------------------|--------------|--------------|-------------------|------------------|---------------|
| ROTATION KIT INSTALLATION. | | | PER NFPA2 | B365-M93 | | |
| See instructions included with that kit. | SIDE | REAR | CORNER * | SIDE | REAR | CORNER * |
| Single Wall Connector | A | B | C | D | E | F |
| | 22" / 560 mm | 12" / 305 mm | 16" / 406 mm | 12" / 305 mm | 12" /305 mm | 8.5" / 216 mm |
| Double Wall Connector | G | H | l | J | K | L |
| | 22" / 560 mm | 6" / 152 mm | 16" / 406 mm | 9" / 229 mm | 4" / 102 mm | 6" / 152 mm |
| Alcove w/ Double-Wall Connector | N/A | N/A | N/A | M 12" / 305 mm | N 7" / 178 mm | N/A |

* Rear Exit chimney connector clearances supercede the stove clearances listed above.





Figure 8a. Clearance Diagrams.

3.4.3 Alcove Installations

The Jøtul F 370 can be installed in an alcove as diagrammed in **fig. 9**.

- 1. The stove must be installed only with double-wall chimney connector.
- 2. Wall protection must extend over the entire area.
- 3. Alcove floor protection must consist of a UL/ULC or WHI listed Type 1 hearth pad or a non combustible material.
- 4. Minimum Alcove Ceiling Height: 72" / 183 cm No alcove ceiling clearance reduction is permitted.



Figure 9. Alcove clearance requirements.

4. Assembly

4.1 Tools & Materials

- work gloves
 safety glasses
- tape measure
 4 mm hex key
- power drill w/ 1/4" and 3/8" drill bits
- 3/8" or 10 mm open end or socket wrench
- 9/16" or 14 mm socket wrench
- ball peen hammer (Rear Exit flue connection only)

4.2 Unpacking the Stove

This stove is shipped in two sections - the Firebox and the Pedestal. Each is secured to its own pallet.

The Firebox includes a decorative Top Flue Outlet Cover Plate (for use with a rear exit chimney connection), and two cast iron Burn Plates, shipped inside the Ash Pan. An Anchor Bracket, Outlet Adaptor Kit, and wooden block are also included inside the firebox.

THE PEDESTAL AND FIREBOX ASSEMBLIES ARE HEAVY!

Be sure to have assistance available when assembling and installing this stove.

Inspect each assembly and immediately report any damage to your local dealer.

1.. From the Firebox Assembly:

Remove the Air Outlet Grille and Top Plate from the stove. These simply lift off the main body.

Remove the Baffle Plate, both Side Panels, Rear Panel, Shaker Grate, Bottom Plate, and Ash Pan from inside of the firebox. See fig. 21 and parts list on pages 21-22.

2. Only if the Rear Exit flue connection is to be used:

• Drill a hole at each of the two dimple locations in the cut-out panels at the back of the stove (fig. 10, A).

• Tap the wooden block into place between the inner top and outer side plates as shown in fig. 10, B. The block will support the side plates against the impact of the hammer as the outlet cut-outs are knocked out.

• Use a ball peen hammer to knock out the panels from the back of the stove.



Figure 10. Removing the rear exit outlet knock-outs.

4.3 Attach the Anchor Bracket to the Pedestal Base

- 1. Use a 4 mm hex key to remove the two countersunk screws and cover plate from the pedestal base. See fig. 11.
- Place the pedestal on its side and use the two, M6 x 20 mm hex bolts to install the anchor bracket to the underside of the base plate as in fig. 12.



Figure 11. Remove cover plate from the pedestal base.



Figure 12.

Attach the anchor bracket to the pedestal base.

4.4 Attach the Firebox to the Pedestal

- 1. Spread a blanket or rug out to protect the floor and carefully lay the firebox on its side.
- 2. Use a 13 mm wrench to remove the four, M8 x 25 mm bolts, shipping brackets, and steel spacers from the bottom of the firebox as shown in fig. 13.
- 3. With assistance, attach the Pedestal to the Firebox as shown in fig. 14 using the four M8 x 25 mm bolts previously removed. Tighten securely.
- 4. Raise the stove into an upright position and place the serialized Approval Label directly under the firebox on the pedestal top plate so that it is accessible from the front of the stove.



4.5 Position the Stove

 Use the clearance diagrams and associated flue collar connection center-line dimensions to determine the stove location appropriate to the clearance requirements specific to your installation. See fig, 8 and 8a on pages 9 and 10.

Measure carefully and position the stove flue collar at the center-line convergence.

Double-check flue collar alignment with chimney connections at the wall thimble or chimney ceiling support adaptor.

4.6 Chimney Connector Installation

4.6.1 Top-exit Orientation

- 1. Replace the Top Plate.
- 2. Attach the crimped end of the first section of chimney connector to the Flue Outlet Adapter with sheet metal screws. Push the Outlet Adaptor fully into the flue collar. Fig. 15.
- 3. From inside the firebox, engage the locking rod through the tabs on the adaptor and secure it with the cotter pin.
- 4. Slide the Air Outlet Grille over the stove pipe into position on the Top Plate.
- 5. Re-check stove clearances to combustible materials and adjust the stove position as necessary.
- 6. Check stove level and plumb and adjust the leveling pads as appropriate.

4.6.2 Rear-exit Orientation

- 1. From inside the firebox, remove the rear Outlet Cover Plate with removal of the two M8 x 20 mm bolts. Fig. 16.
- 2. Remove the Flue Collar from the top plate and re-install it in the rear outlet position inside the firebox. Fig. 16.
- 3. Attach the crimped end of the first section of chimney connector to the Flue Outlet Adapter with four sheet metal screws. Push the Flue Outlet Adaptor into the flue collar from outside the stove. From inside the stove, insert the bent end of the locking rod through one of the tabs, then slide the other end into the opposite tab. Secure the rod with the cotter pin.
- 4. Re-install the Flue Outlet Cover Plate over the top outlet inside the firebox.
- 5. Replace the Top Plate, Air Outlet Grille, and decorative Flue Outlet Cover Plate.





Figure 16. Outlet Cover Plate and Flue Collar.

4.7 Secure the stove to the hearth

1. At the anchor bracket hole, drill a 1/4" dia. pilot hole through the hearth and into the floor material.

NOTE: For masonry floor materials, install a 3/8" dia. lead bolt anchor or shield into the floor.

- 2. Open the pilot hole in the hearth material to 3/8" diameter to avoid cracking.
- 3. Secure the pedestal base to the hearth using the supplied 2 1/2" lag bolt and 9/16" socket wrench.
- 4. Replace the anchor cover plate and secure it with the two acorn nuts supplied with the anchor bracket.

4.8 Final Assembly

- 1. Replace the Ash Pan within the ash pan compartment.
- 2. Replace the Bottom Plate and Shaker Grate in the stove bottom.
- 3. Replace the Rear and Side skamol panels.
- 4. Place the two cast iron Burn Plates into position under the side windows. Fig. 17, A.
- 5. Replace the Smoke Baffle/Manifold in position in the upper firebox. It rests upon the side and rear skamol panels.



Figure 17. Install the cast iron burn plates.

5.0 Operation

Please read the following section before building the first fire in your new Jøtul F 370.

5.1 Combustion Efficiency

EPA qualified tested efficiency values are not currently available for the F 370. The EPA default efficiency for noncatalytic wood heaters is 63% per Federal Register 40 CFR Part 60, Subpart AAA.

There are, however, aspects of efficiency that you should be aware of in order to get the most from your stove.

Operation habits and fuel moisture can have a significant effect on efficiency. Poorly seasoned wood having a higher than optimum moisture content, can reduce the amount of energy transferred to the living area as a result of the energy expended to evaporate the excess fuel moisture in order for the wood to burn. Operational aspects, such as not building a robust kindling fire to readily ignite the larger fuel pieces, can result in an inefficient smoldering fire. Additionally, most modern wood heaters' optimum performance and efficiency are at the medium to medium -low burn rates.

The location of the stove can have a significant effect on heating efficiency, primarily in regards to distribution of the heat. For example, a wood heater centrally located in the residence in an open living area will likely provide better circulation of heat than will a stove located in a room adjacent to the larger living area.

5.2 CO Emissions

EPA qualified tested carbon monoxide (CO) values ar not currently available for the F 370. There are, however, aspects of CO that you should know. Most all means of combustion produce CO, including wood fires. Maintaining a well-established fire and avoiding operation that produces a smoldering, smoky fire, will greatly reduce CO levels.

It is highly recommended that a CO monitor (detector) be installed in the same room as the stove. The monitor, however, should be located as far away as possible from the stove to avoid alert soundings when adding fuel to the fire.

5.3 Wood Fuel and Stove Performance

The F 370 is designed to burn natural wood only. Higher efficiencies and lower emissions generally result when burning air-dried, seasoned hardwoods, as opposed to softwoods, green or freshly cut hardwoods. Wood that has been air-dried for a period of 6 to 14 months will provide the cleanest, most efficient heat. Wood seasoned more than 2 years will burn too quickly to take advantage of the stove's low end efficiency strength.

A seasoned log will have check marks on the ends and be lighter than an unseasoned log which will show little or no check marks. WARNING ALWAYS WEAR STOVE GLOVES WHILE TENDING THE FIRE.

NEVER ALLOW THE FIRE TO REST DIRECTLY ON THE GLASS. KEEP THE LOGS SPACED AT LEAST ONE INCH FROM THE GLASS TO ALLOW FOR PROPER AIR FLOW WITHIN THE STOVE. AVOID STRIKING THE GLASS WITH LOGS.

OPERATE THIS STOVE ONLY WITH THE FRONT DOOR AND ASH DOOR FULLY CLOSED. OPERATION WITH THE DOOR PARTIALLY OPEN MAY RESULT IN OVER-FIRING. IF THE DOOR IS LEFT PARTIALY OPEN, GAS AND FLAME MAY BE DRAWN OUT OF THE STOVE CREATING SAFETY RISKS FROM BOTH FIRE AND SMOKE.

We recommed using a moisture meter to determine the moisture content of your wood. For purposes of home heating, your fuel should have a moisture content between 12 - 20%. Wood with higher moisture content will burn, however, very inefficiently. Most of its heat value will be lost to driving water out of the wood. Worse, that moisture will condense as creosote in the relatively cool chimney flue, increasing the potential for a chimney fire. Use of unseasoned wood defeats the purpose of any modern wood-burning stove.

DO NOT BURN:

- Coal;
- Garbage;
- Synthetic fuel or logs;
- Material containg rubber, including tires;
- Material containing plastics;
- Waste petroleum products, asphalt products, paints, paint thinners or solvents;
- Materials containing asbestos;
- Construction or demolitioin debris;
- Railroad ties or pressure-treated wood;
- Manure or animal remains;
- Salt water driftwood or other previously salt-water; saturated materials;
- Unseasoned wood; or

• Paper products, cardboard, plywood, or particle board. (The prohibition against burning these materials does not prohibit the use of fire starters made from paper, cardboard, saw dust, wax or similar substances for the purpose of starting a fire.)

The burning of any of these materials can result in the release of toxic fumes, or render the heater ineffective and cause smoke. Never use gasoline, gasoline-type lantern fuel, kerosene, charcoal lighter fluid, or similar liquids to start or "freshen-up" the fire. Always keep such liquids away from the heater at all times.

5.4 Air Control Settings

A single lever regulates the Primary Air flow that controls the intensity of the fire and consequent heat output and burn time. The lever is located within the slot above the stove door.

Primary Air enters the stove above the door and washes over the glass before reaching the fuel. A second source of primary air reaches the fire through the small pilot tube at the front of the firebox. Unrestricted secondary air is delivered through manifolds at the rear and top baffle where it ignites volatile gases that would otherwise pass unburned into the environment. See fig. 18. In this way, the wood is burned efficiently and exhaust is minimized. When the fire is burning well, little or no smoke will be evident from the chimney.

When first starting or reviving the fire, the control lever should be set at the far right position to allow the maximum amount of air into the stove. See fig. 19. After the fire is well-established, the lever should be set at position to moderate incoming air to maintain the desired long term heat output and/or burn time.

In general, the more air made available to the fuel will result in the hottest fire intensity and the fastest fuel consumption. Alternatively, the less air made available to the firebox will result in low heat output and slower fuel consumption.

5.5 Break-in Period

The cast iron parts of your stove require a break-in process to allow them to gradually adjust to thermal expansion and contraction. This is accomplished by building a series of three or four fires, each somewhat hotter than the last. Use a stove-top thermometer to monitor fire intensity and top plate temperature.

Adjust the Air Control lever to the Fully Open position. Limit the first fire to only kindling and a couple of 1 -2 inch logs, keeping the temperature under 300°F. Allow the fire to burn out and return the stove to room temperature before building another fire.

Build progressively larger fires, maintaining intensity in +100°F increments, and allowing the stove to cool after each one. Keep the Air Control set to the fully open position.

NOTE: *It is normal* for a new, painted stove to emit odor and smoke during initial fires, depending upon temperatures over time. This is caused by the seasoning of the high temperature paint and production material. Opening a window or door to provide additional ventilation will alleviate this condition.





5.6 Starting and Maintaining a Fire

Burn only solid wood directly on the bottom plate of the stove. Do not elevate the fire in any way.

- 1. Set the Air Control Lever in the full open position, all the way to the right. Crumple several sheets of newspaper directly on the bottom plate.
- 2. Place several pieces of small dry kindling (approx. 1" in diameter) on top of the newspaper, with two to three small split logs (approx. 2" to 3" in dia.) on top.
- 3. Light the fire and close the door. Gradually build the fire by adding larger and larger logs as the fire develops a bed of coals.
- 4. When you have added the final logs, adjust the Air Control Lever to provide the desired fire intensity.

Experiment with a variety of air control settings to determine the best one for your individual circumstances. Remember that fuel characteristics, chimney system condition, building design, and weather conditions all affect the performance of your stove. In time, you will discover how these elements combine and how you can work with them to achieve satisfactory performance.

5.7 Adding Fuel to the Fire

When reloading the stove while a bed of hot embers still exists, follow this reloading procedure:

- Always use the stove mitt when tending to the fire.
- *Before you open the door,* push the Air Control Lever to the full open position (far right).
- Always wait a few seconds before opening the door. This allows the renewed air circulation to clear unburned gases from the firebox. Hold the door open just slightly for a couple of seconds before opening it fully. This will also help ensure that no smoke escapes into the room.
- Use a stove tool or poker to distribute the hot embers equally around the firebox and push ashes into the ash pan.
- Load the fuel, usually with smaller logs first.
- Close the door and secure the latch.
- Wait 5 10 minutes for the fire to reestablish itself before adjusting the Air Control Lever for the desired heat output. If a thick bed of live coals is present, you may be able to add fuel and immediately set the air control without waiting for the fire to be reestablished.

WARNING!

NEVER OVER-FIRE THE STOVE. IF ANY PART OF THE STOVE OR CHIMNEY GLOWS, YOU ARE OVER-FIRING. A HOUSE FIRE OR SERIOUS DAMAGE TO THE STOVE OR CHIMNEY COULD RESULT. IF THIS CONDITION OCCURS, IMMEDIATELY CLOSE THE AIR CONTROL.

5.8 Creosote Formation and the Need for Removal

When wood is burned slowly, it produces tar and other vapors that combine with moisture to form creosote. Creosote vapors condense in the relatively cool chimney flue, and creosote residue accumulates on the flue lining. When ignited, this creosote fuels an extremely hot fire.

The chimney connector and chimney flue should be inspected at least every two months during the heating season to determine if creosote buildup has occurred.

If creosote has accumulated, it should be removed to reduce the chance of a chimney fire. A qualified chimney sweep or other authorized service person can provide this service.

It is also important to remember that chimney size, temperature and height all affect draft which in turn affects the formation of creosote. An exterior chimney, whether masonry or prefabricated steel, will be exposed to cold outside temperatures, and consequently, will be more prone to creosote accumulation than an interior flue.

A chimney flue located within the home interior will benefit from the insulating characteristics of the building itself. Consequently, the flue system will be less conducive to condensation of unburned gases and minimal creosote accumulation will result.

As a general rule, try to avoid burning the stove at the lowest air control settings. Although a low setting will prolong burn time, it may also result in incomplete combustion. In reducing the fire intensity, draft is weakened and the chimney flue cools. This, together with the increase in unburned gases, can lead to rapid creosote accumulation.

In the event that creosote ignites in the flue, the resulting fire is often accompanied by a roaring noise and crackling sound as flakes of burning creosote break loose. If you suspect you are having a chimney fire, immediately close the air controls and make sure the door is closed securely. Call the fire department and have everyone leave the house.

Do not attempt to extinguish the fire. Opening the door will only supply additional oxygen and intensify the fire. When the fire in the flue has subsided, resist the temptation to open the door to check on the fire. The fire may have suffocated, but could re-ignite with a supply of fresh air. After a chimney fire, do not use the stove until the chimney connector and flue have been cleaned and inspected to ensure no damage has been sustained.

See Section 7.2 of this manual regarding chimney cleaning.

6. Maintenance

6.1 Ash Removal

Ash removal will be required periodically depending upon how frequently the stove is used. Always use the stove mitt when handling ashes. Use a steel ash shovel or poker to push ashes through the bottom grate into the ash pan. This will minimize dust in the living area. Carry the ash pan outdoors and empty into a steel container with a tight-fitting lid. **NEVER USE A PAPER OR PLASTIC BAG AS AN ASH RECEPTACLE.**

The container of ashes should be placed on a noncombustible floor or on the ground, well away from all combustible materials, pending final disposal. If the ashes are disposed of by burial in soil or otherwise dispersed, **they should be kept in the closed container until all coals and cinders have thoroughly cooled.**

6.2 Chimney System Inspection and Cleaning

The Jøtul F370 is designed to burn cleanly and efficiently when used according to the guidelines in this manual. In order to maintain proper performance, you should inspect the chimney and chimney connector at the beginning of each heating season and then at least every other month during the heating season. Clean the chimney whenever creosote and fly ash accumulation exceeds 1/4 inch in any part of the system.

Chimney brushes are available from your local Jøtul dealer or hardware supply store. Your dealer can also refer you to a reputable, professional chimney sweep who will have all the equipment to ensure a complete and proper job.

WARNING: FAILURE TO KEEP THE CHIMNEY CONNECTOR AND FLUE FREE OF CREOSOTE BUILD-UP CAN RESULT IN A CHIMNEY FIRE.

6.3 Glass Care

6.3.1 Cleaning

While the air wash design will help keep the glass clean, it is normal for some soot to accumulate on the glass surface during low burn periods. This will clear off during the next hot fire. Occasionally it will be necessary to clean the carbon deposits and fly ash off of the glass. If deposits are allowed to remain on the glass for an extended period of time, the glass may become etched and cloudy.

- 1. The glass must be COMPLETELY COOL.
- 2. Only use a cleaner that is specifically designed for this purpose. DO NOT USE ABRASIVE OR AMMONIA-BASED CLEANING AGENTS. The use of abrasives will damage the glass, leaving a frosted surface. Crumpled newspaper is an especially good cleaning material.
- 3. Rinse and dry glass completely before lighting a fire.

6.3.2 Glass Replacement

Side Glass, Inner

Always operate the door slowly and cautiously to avoid cracking or breaking the glass. Never use the door to push wood into the firebox. If the glass becomes cracked or broken follow the replacement procedure below.

| NEVER OPERATE THE STOVE WITH A CRACKED OR BROKEN GLASS PANEL. | | | | |
|---|------------------------|--|--|--|
| Replace glass only with panels specifically | | | | |
| designed for the J | øtul F 370. Do not use | | | |
| substitutes. Replacement glass can be | | | | |
| ordered from your Jøtul dealer. | | | | |
| Door Glass | 221648 | | | |
| Side Glass, Outer | 223210 | | | |

1. First loosen and then carefully remove the four glass clips from the inside of the door. See fig. 20.

223209

- 2. Remove all pieces of the glass panel and gasketing.
- 3. Remove all remaining debris from the glass area using a wire brush.
- Apply a small bead of gasket/stove cement and the new gasket. Do not overlap the ends of the gasket rope.
- Center the new glass panel over the gasket and loosely reinstall the glass clips. Tighten the clips, alternating at opposite corners. Avoid applying uneven pressure on the glass.
- 6. It may be necessary to retighten the glass clips after the stove has burned and the gasketing has seated.

The procedure is the same for the side glass panels. Consult fig. 20 for glass clip and gasketing orientation.



Figure 20. Glass and gasket replacement.

6.4 General Maintenance

Regular maintenance will assure proper performance and prolong the life of your stove. The following procedures do not take long and are generally inexpensive. When done consistently, they will help increase the life of your stove and assure satisfactory performance.

- Empty firebox of all soot and ashes. Never use a household vacuum cleaner to remove ashes. Only an ash vacuum with a metal container is acceptable and only when you are certain the ashes are completely cold.
- Inspect the firebox using a utility light inside and out for cracks or leaks. Replace cracked or broken skamol burn plates. These are wear parts and may require replacement from time to time.

| Left and Right Burn Plates | 223393 |
|----------------------------|--------|
| Rear Burn Plate | 221805 |
| Top Baffle | 223292 |

• Clean the exterior cast iron surfaces with a soft, damp cloth. Use Jøtul High-temperature Satin Black paint to keep your stove looking new.

6.5 Gaskets

Check door and glass gaskets for seal integrity. The gaskets should be soft enough to be somewhat resilient to the touch. Over time, gaskets will compress and harden. Replace worn-out or hardened gaskets with the appropriate size material available from your local Authorized Jøtul Dealer.

To check the seal of the front door, close and latch the door on a dollar bill and slowly try to pull the dollar bill free. The seal is too loose if the bill can be easily removed. Adjust the door latch and test again.

6.5.1 Gasket Replacement

See the chart below for replacement gasket specifications.

- 1. Remove the old gasket material with a pliers and thoroughly clean the channel with a wire brush.
- 2. Lay out the new gasket around the channel to determine length. Trim the gasket to leave 1" excess.
- 3. Apply a small bead of gasket or furnace cement in the channel.
- 4. Lightly press the new gasket into the channel, being careful to avoid compressing or stretching it. Trim the gasket further as necessary to allow the tail end to slightly overlap the other end.
- 5. Wait ten minutes to allow the cement to set and then close and latch the doors. Reopen the doors and use a damp cloth to wipe away any excess cement that may be squeezed out from under the gasket.

| Replacement Gaskets | | |
|---|------------------|--|
| Door & Door Glass Gasket Kit | 157050 | |
| Door Glass Gasket LD .250-2 Ø6 Fiberglass Rope 80" | 200024 | |
| Door Gasket LD .375-2 Ø9 Fiberglass Rope 96" | 129296 | |
| Side Glass Gasket, inner & outer LD .250-2 Ø6 Fiberglass Rope 80" | 200024 | |
| Flue Outlet Cover Plate & Flue Collar LD .250-2 Ø6 Fiberglass Rope 24" | Gasket 200024 | |

7. Jøtul F 370 Illustrated Parts Diagram



Jøtul F 370 Parts List

| No. | Description | Part Number |
|-------------|---|-------------|
| 1. | Screw, Hex Cap, M8 x 20 | 117875 |
| 2. | Screw, Hex Hd Bolt, M8 x 12 | 99115 |
| 3. | Air Manifold, Rear | 10448312 |
| 4. | Rear Plate | 10446718 |
| 6. | Glass Holder, Right - inc. 5(1),30,62,63,67,68 (2 pcs.e | a.) 156844 |
| 7. | Side Plate, Right - BP | 10446592 |
| 8. | Gasket, Bottom Plate - LD 250-2 Ø6,4 x 930mm | 200024 |
| 9. | Gasket, Ash Pan Rider - LD 250-2 Ø6,4 x 785mm | 200024 |
| 10. | Bottom Plate | 157147 |
| 11. | Nut, Flange Hd Hex - M6 | 117968 |
| 12. | Lock Lower Door | 10447318 |
| 13. | Sleeve, 2 x 15 mm | 126109 |
| 14. | Cover, Side Bolt | 10460212 |
| 15. | Screw, Hex Cap Flange - M6 x 16 | 99625 |
| 16. | Screw, Phillips - M6 x 12mm | 117976 |
| 17. | Nut, Hex Cap Flange Hd, M8 | 117881 |
| 18. | Sleeve, 10 x 8.2 x 10 mm Steel | 223324 |
| 19. | Screw, Socket Hd Cap, M6 x 35 | 117789 |
| 21. | Secondary Air Manifold Assembly, Top | 222786 |
| 22. | Secondary Air Manifold, Rear | 222787 |
| 23. | Primary Air Tube | 222797 |
| 24. | Door Hinge, Lower / Cast Iron | 10447218 |
| 26. | Front Plate, BP | 10446692 |
| 28. | Ash Pan, Complete Assembly | 157180 |
| 29. | Screw, Countersunk Internal Hex, M8 x 40 | 116913 |
| 30. | Gasket, V-125 x 40mm | 127215 |
| 31. | Gasket, Side Glass - Outer, toward Front | 200024 |
| 32. | Gasket, Side Glass - Outer, toward Side | 200024 |
| 33. | Side Plate, Left - BP | 10446492 |
| 34. | Glass, Side Outer -Rt & Lt | 222157 |
| 35. | Glass Holder, Left - inc. 5(1),30,62,63,67,68 (2 pcs.ea | .) 156845 |
| 36. | Handle Shield | 223294 |
| 37. | Screw, Hex Cap Flange M8 x 40 | 117879 |
| 38. | Gasket, LD 250-2 Ø6 -4 x 600mm | 200024 |
| 39. | Air Outlet, Top - BP | 10441692 |
| 40. | Top Outlet Filler - BP | 10441792 |
| 41. | Top Plate, Upper - BP | 10447092 |
| 42. | Smoke Outlet, Ø150 mm | 156240 |
| <u>4</u> 3. | Top Plate, Lower | 10433818 |
| 44. | Push Nut, Ø6 x Ø15 mm Blk | 117859 |

| No | Description Par | t Number |
|-------------|--|------------|
| 46. | Smoke Outlet Cover Plate | 10441112 |
| 47. | Air Valve - BP | 22329892 |
| 48. | Gasket, Air Tube - Manninglass | 223310 |
| 49.** | Burn Plate, Rear - Skamol | 223293 |
| 50. | Air Manifold, Front | 10433912 |
| - 51.** | Burn Plate, L & R Side - Skamol | 221805 |
| - 52.** | Baffle - Skamol | 223292 |
| 53. | Washer, Ø6.2 x 12 x 1.8 Brass | 128632 |
| 54. | Burn Plate, Lower - L & R, cast iron | 10447512 |
| 55. | Grate | 10434912 |
| 56. | Bottom Plate, Inner | 10434812 |
| - 57. | Screw, Hex Cap Flange, M8 x 25mm | 117876 |
| 59. | Screw, Hex Cap Flange, M6 x 10mm | 9962 |
| 60. | Screw, Countersunk Cap Internal Hex - M8 x 16mm | 117739 |
| 61. | Glass, Side - Inner, L & R | 221867 |
| 62. | Gasket, Glass Holder LD 250-2 Ø6,4 x 40mm | 200024 |
| 63. | Gasket, Glass Holder LD 250-2 Ø6,4 x 1000mm | 200024 |
| 66. | Washer, Ø6 x Ø12 x 0.5mm | 117588 |
| 67. | Glass Clip, Side Inner Glass - inc. gasket | 153620 |
| 68. | Screw, Cylinder Head Internal Hex - M6 x 12mm | 118231 |
| 69. | Glass Clip, Door Glass | 128412 |
| 70. | Screw, Countersunk Cap Internal Hex - M6 x 10mm | 117977 |
| 71. | Door Hinge, Steel (2) - BP | 22166292 |
| 73 . | Door Handle | 223309 |
| 75·* | Bolt, Serrated Flange Hex Hd, M6 x 20mm Blk, (2) | 117117 |
| 76. | Door Latch Assembly | 221659 |
| 77· | Gasket, Door to Front Plate - LD 375-2 Ø9, 5 x 2100mm | 100038 |
| 78. | Door, BP | 10446392 |
| 79· | Door Glass, Ceramic | 221648 |
| 80. | Gasket, Door Glass - LD 250-2 Ø6,4 x 2000mm | 200024 |
| 81.* | Acorn Nut, (2) | 118253 |
| 82. | Door Handle Bumper | 221897 |
| 83.* | Bolt, Lag 3/8" x 2.5", 1 | 118252 |
| 84.* | Bracket, Anchor, 1 | 224499 |
| 85. | Upper Hinge Assembly | 157186 |
| 86. | Upper Door Catch Assembly | 157187 |
| 87.* | Outlet Adaptor Asy. inc. Locking Rod and Cotter Pin | 222793 |
| 106. | Pedestal Top | 10448712 |
| 109. | Brake Cover - BP | 10453692 |
| 110. | Pedestal Bottom - BP | 10449192 |
| 112. | Screw, Hex Cap - M8 x 16 | 9912 |
| 113. | Pedestal Side - BP | 10448892 |
| | * Adaptor Kit - inc. Outlet Adaptor and Pedestal Anchor Hardwa | are 157373 |
| | ** Skamol Panel Kit includes 49, 51 (L&R), and 52 | 157682 |

Use only genuine Jøtul replacement parts. Do not substitute parts from any other manufacturer. See your local Authorized Jøtul Dealer or contact us directly:

Jøtul North America 55 Hutcherson Dr. Gorham, Maine 04038

9. Jøtul Wood-burning Product Limited Lifetime Warranty

Effective January 1, 2013

This warranty policy applies to wood-burning products identified by Jøtul and Scan trade names, as set forth below.

A. LIMITED LIFETIME WARRANTY, parts only: Jøtul North America Inc. (JØTUL) warrants, to the original retail purchaser, that those baffle and air manifold components of the Jøtul or Scan Stove or Fireplace Insert specified above will be free of defects in material and workmanship for the life of the product. This warranty is subject to the terms, exclusions and limitations set forth below.

B. LIMITED FIVE YEAR WARRANTY - Cast Iron and Steel Components: JØTUL warrants, to the original retail purchaser, that those components of the Jøtul or Scan Stove or Fireplace Insert specified above will be free of defects in material and workmanship for a period of five (5) years from the date of purchase. This warranty is subject to the terms, exclusions and limitations set forth below.

C. LIMITED TWO YEAR WARRANTY - Enamel Finish: JØTUL warrants, to the original retail purchaser, the enamel finish on cast iron components of the Jøtul Stove or Fireplace Insert specified above against peeling or fading for a period of two (2) years from the date of purchase. This warranty is subject to the terms, exclusions and limitations set forth below.

D. LIMITED ONE YEAR WARRANTY - Electrical Components (blowers, thermostatic switches): JØTUL warrants, to the original retail purchaser, that those components of the Jøtul or Scan Stove or Fireplace Insert specified above will be free of defects in material and workmanship for a period of one (1) year from the date of purchase. This warranty is subject to the terms, exclusions, and limitations set forth below:

JØTUL will repair or replace (including parts & labor), at its option, any of the above components determined by JØTUL to be covered by this warranty. You must, at your own expense, arrange to deliver or ship the component to an authorized Jøtul or Scan dealer and arrange for pickup or delivery of the component after repairs have been made. If, upon inspection, JØTUL determines that the component is covered by this warranty, the repair or replacement will be made as set forth above. This warranty is not transferable and is extended only to, and is solely for the benefit of, the original retail purchaser of the Jøtul or Scan Stove or Fireplace. This paragraph sets forth the sole remedy available under this warranty in the event of any defect in the Jøtul or Scan Stove or Fireplace.

The warranty period for any replaced component will be the remaining unexpired portion of the warranty period for the original component.Please retain your dated sales receipt in your records as proof of purchase.

Exclusions and limitations

Notice: This warranty is void if installation or service is performed by someone other than an authorized installer or service agency, or if installation is not in conformance with the installation and operating instructions contained in this owner's manual or local and/or national fire and building regulations. A listing of local authorized installers, service agencies and gas suppliers can be obtained from the National Fireplace Institute at http://www.nficertified.org/.

This warranty does not cover the following:

- Repair or replacement of parts that are subject to normal wear and tear during the warranty period or to parts that may require replacement in connection with normal maintenance. These parts include paint, gaskets, burn plates, baffles, air manifolds, firebricks, fire grates, or glass (glass is only warranted against thermal breakage).
- Damage due to incorrect installations not in conformance with the installation instructions contained in this owner's manual or local and/or national fire and building regulations.
- 3. Damage, including damage to enamel surfaces, caused by improper operation, over-firing, and/or misuse. Improper operation, such as burning the stove with the ash door open, can damage the stove. Over-firing occurs when any part of the stove glows red. Over-firing can also be identified by warped plates, rust-colored cast iron, paint pigment that has turned dusty white, or bubbling, cracking and discoloration of the enamel finish. Misuse includes, without limitation, use that is not in conformance with the operating instructions contained in this owner's manual.
- Damage due to service performed by an installer or service agency, unless otherwise agreed to in writing by JØTUL.
- 5. Damage caused by unauthorized modification, use or repair.
- 6. Costs incurred by travel time and/or loss of service.
- 7. Labor or other costs associated with the repair of components beyond the warranty period.
- Damage incurred while the Jøtul or Scan Stove or Fireplace is in transit.

IN NO EVENT SHALL JØTUL, ITS PARENT COMPANY, SHAREHOLDERS, AFFILIATES, OFFICERS, EMPLOYEES, AGENTS OR REPRESENTATIVES BE LIABLE OR RESPONSIBLE TO YOU FOR ANY SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR OTHER SIMILAR DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, LOST SALES, INJURY TO PERSON OR PROPERTY, OR DAMAGES TO A STRUCTURE OR ITS CONTENTS, ARISING UNDER ANY THEORY OF LAW WHATSOEVER. ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS WRITTEN WARRANTY. EXCEPT AS EXPRESSLY SET FORTH HEREIN, JØTUL MAKES NO ORAL, WRITTEN OR OTHER WARRANTY WITH RESPECT TO JØTUL OR SCAN STOVES OR FIREPLACES.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on the length of implied warranties. Therefore, the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

JØTUL reserves the right to discontinue, modify or change the materials used to produce the Jøtul or Scan Stove or Fireplace. JØTUL shall have the right to replace any defective component with substitute components determined by JØTUL to be of substantially equal quality and price.

The dollar value of JØTUL's liability for breach of this warranty shall be limited exclusively to the cost of furnishing a replacement component. JØTUL shall not in any event be liable for the cost of labor expended by others in connection with any defective component. Any costs or expenses beyond those expressly assumed by JØTUL under the terms of this warranty shall be the sole responsibility of the owner(s) of the Jøtul or Scan Stove or Fireplace.

No dealer, distributor, or other person is authorized to modify, augment, or extend this limited warranty on behalf of JØTUL. NO MODIFICATION OR CHANGE TO THIS WARRANTY WILL BE EFFECTIVE UNLESS IT IS MADE IN A WRITTEN DOCUMENT MANUALLY SIGNED BY AN AUTHORIZED OFFICER OF JØTUL.

An authorized installer may have been provided with certain information related particularly to the Jøtul or Scan Stove or Fireplace; however, no authorized installer or other person who may service the appliance is an agent of JØTUL. No inference should be made that JØTUL has tested, certified, or otherwise pronounced any person as qualified to install or service the appliance. JØTUL shall not be liable or otherwise responsible for any error or omission by a person installing or servicing a Jøtul or Scan Stove or Fireplace.

If you believe your Jøtul or Scan Stove or Fireplace is defective, you should contact your nearest authorized Jøtul or Scan dealer, who will process a warranty claim. IN ORDER TO QUALIFY FOR WARRANTY COVERAGE, JØTUL MUST RECEIVE NOTICE OF A POSSIBLE DEFECT WITHIN SIXTY (60) DAYS OF THE DATE THE DEFECT IS FIRST DISCOVERED, OR REASONABLY COULD HAVE BEEN DISCOVERED.

This warranty is given by Jøtul North America, Inc., 55 Hutcherson Drive, Gorham, Maine 04038 USA

| 139683_R02 February, 2016 | |
|------------------------------|---|
| | This appliance must be installed in conformance with local and national building regulations. It is important that these instructions be carefully read and understood before beginning the installation. Jøtul pursues a policy of continual product development. Consequently, products may differ in specification, color or type of accessories from those illustrated or described in various publications. |
| | Jøtul North America, Inc. 55 Hutcherson Dr. Gorham Maine 04028 |
| | Gornam, Maine 04038 USA Jøtul AS P.O. Box 1411 N-1602 Fredrikstad, Norway |